



















 <b>BERGER TOOLS LTD</b>
Spare Parts List For Type MH-500-B

Description	Repair Kits					
	FB34027238	FB34027323	FB34027325	FB34027327	FB34027329	FB34027331

	E501 B	Hex. Bolt M10x270 with 2 Nuts & 3 Washers each	4	4	4	4	4	4
	E522 B	Guide Block						
	E502/1 B	Upper Housing						
	E503 b	Seal				1		
	E502/2 B	Tube						
	E504 B	Disc screw M6x16 with Washer				1		1
	E505 B	Support Disc - Upper						1
	E506 B					1		
	E508 B	Diaphragm				1		
	E509 B	Piston Support						
	E510 B	Pusher Rod					1	
	E511 B	Flange			1			1
	E512 B	Bolt M6x10 with Spring Washer			5		5	5
	E514 B	Spring			1			
	E520/1 B	Tube						
	E515 B	Guide Bush D28x20xL22	1	1			1	
	E520/2 B	Lower Housing without Feet	1					
	E515 B	Guide Bush D28x20xL22	1	1			1	